CONTINUOUS WAVE TERAHERTZ EMITTER AND DETECTOR MODULES





AT A GLANCE

Photomixers for 1.5 µm optical wavelength, emitted THz power confirmed by PTB (Physikalisch Technische Bundesanstalt)

Features

- Up to 200 μW THz power
- Photodiode based emitter
- Photoconductive receiver
- Robust housing and fiber coupling


Applications

- High-bandwidth terahertz spectroscopy
- Industrial process control
- Non-contact coating film thickness measurement
- High-speed measurements

Technical background

The photoconductive generation of continuous wave (cw) terahertz radiation converts the beat frequency of two lasers into an electrical THz signal. The frequency resolution of cw THz systems is only limited by the linewidth of the lasers. Preferred applications for continuous wave THz radiation are high resolution spectroscopy and imaging as well as precise monitoring of particular spectral lines. HHI's THz modules utilize mature telecom technology and thus allow benefiting from THz technologies within industrial applications and environments.





Performance of HHI's cw THz modules for operation conditions as given in the specifications.

Specifications

 Optical wavelength 	1.5 μm
 Optical power 	30 mW
 Bias voltage 	-1.5 V
 Spectral range 	0.1 - 3.5 THz
Dynamic range	> 90 dB @ 100 GHz (typ. 100 dB) > 60 dB @ 1 THz (typ. 65 dB) > 40 dB @ 2 THz (typ. 45 dB)
Measuring head diameter	25 mm

Bjoern Globisch

Photonic Components

Phone +49 30 31002-415 bjoern.globisch@hhi.fraunhofer.de

Fraunhofer Heinrich Hertz Institute Einsteinufer 37, 10587 Berlin Germany

www.hhi.fraunhofer.de/pc